


MS365
0708
0004



# POSITIVE DISPLACEMENT FLOWMETERS

## M50 SERIES INSTRUCTION MANUAL

M50 Mechanical meter; From serial No.CXXXX



### TO THE OWNER

Please take a few minutes to read through this manual before installing and operating your meter.

Always retain this manual for future reference.

If you have any problems with the meter, refer to the maintenance and trouble shooting sections of this manual.

This manual contains connection and operating instructions for meters with mechanical displays.

If you need further assistance, contact your local representative or distributor for advice.

This Flow Meter has incorporated the oval rotor principal into its design. This has proven to be a reliable and highly accurate method of measuring flow.

Exceptional repeatability and high accuracy over a wide range of fluid viscosities and flow rates are features of the oval rotor design. The low pressure drop and high pressure rating means oval rotor flow meters are suitable for both gravity and pump (in line) applications.

Flow meters are available in either Aluminium or 316 Stainless Steel. Standard rotors are made from PPS (Polyphenylene Sulfide Resins) with optional 316 Stainless Steel rotors available for both Stainless steel and Aluminium models.

Mechanical displays have a re-settable batch totaliser and non-re-settable accumulative totaliser.

## IMPORTANT INFORMATION



### PLEASE READ THIS INFORMATION CAREFULLY BEFORE USE!

Before use, confirm the fluid to be used is compatible with the meter. Refer to Industry fluid compatibility charts or consult your local representative for advice.

To prevent damage from dirt or foreign matter it is recommended that a Y or basket type 60 mesh strainer be installed as close as possible to the inlet side of the meter. Contact your local representative for advice.


**Note:** When a strainer is installed it should be regularly inspected and cleaned. Failure to keep the strainer clean will dramatically effect flow meter performance.

**Note:** To prevent damage caused by air purge slowly fill the meter with fluid. To reduce pressure build up turn off the pump at the end of each day.


When maintenance to any other part of the meter is required, the meter must be isolated and the line pressure reduced. Contact your meter distributor for further information.

## OPERATING PRINCIPLE

When fluid passes through the meter the rotors turn, as shown below. The gear located on top of one of the rotors drives the mechanical registers gear train which provides an accurate readout.



## INSTALLATION



1) It is recommended that when setting up pipe work for meter installations a bypass line be included in the design. This provides the facility for a meter to be removed for maintenance without interrupting production. (See Fig.1)


2) Use thread sealant on all pipe threads. For flanged versions appropriate companion flanges and gaskets are required.

3) For pump applications ensure pipe work has the appropriate working pressure rating to match the pressure output of the pump.

4) Install a wire mesh strainer (Y or basket type) as close as possible to the inlet side of the meter.

5) Ensure that the meter is installed so that the flow of the liquid is in the direction of the arrows embossed on the meter body.

6) The meter can be installed in any orientation as long as the meter shafts are in a horizontal plane. (Refer to Fig.2 for correct installation). The register assembly may be orientated to suit the individual installation.



Do Not Install Meter This Way

2

**Note:** Incorrect installation can cause premature wear of meter components.

7) Do not over tighten meter connections.

8) It is important that after initial installation you fill the line slowly, high speed air purge could cause damage to the rotors.

9) Test the system for leaks.

10) Check the strainer for swarf or foreign material, after the first 200 litres check periodically, particularly if the flow rate decreases.

## SERVICE INSTRUCTIONS

### Disassembly

Ensure that the fluid supply to the meter is disconnected, and the line pressure is released before disassembly.

Refer to the exploded parts diagram on subsequent pages for item numbers.

1) Remove the four screws (Item 17) located on the face of the register.  
Then remove the face plate cover including register assembly.

2) Remove the four register mounting screws (Item 15). Then remove the lower half of the register housing.

3) Remove the six cover plate screws (Item 12) and remove the cover plate (Item 11).

4) Remove the eight meter cap screws (Item 5) and remove the meter cap (Item 4).

5) Remove rotors (Item 3).

### Reassembly

1) Clean all components before reassembly.

2) Before reassembly check the condition of the rotors (Item 3). Replace if necessary.

3) Replace the rotor (with the gear) on the short shaft in the housing then place the 2nd rotor onto the shaft so as the rotors are at 90° to each other. (Refer Fig 3). Check rotor operation by turning either of the rotors. If the rotors are not in mesh correctly or do not move freely remove one of the rotors and replace it correctly at 90° to the other rotor. Recheck the operation of the rotors.

4) Inspect the gears (Item 6) in the meter cap (Item 4) for wear. (Replace if required, refer to spare parts on page 5).

5) Replace the o-ring (Item 2) into the groove in the meter cap, if the o-ring has been distorted or is damaged in any way replace it with a new part.

6) Replace the meter cap, making sure the locating pins line up with the holes in the meter cap and the gear on the rotor meshes correctly with the gear in the meter cap (Item 4). Insert the allen screws (Item 5) and tighten in the sequence 1, 4, 2, 5, 3, 6.

7) Inspect the bevel gear (Item 13), o- ring (Item 10), and output gear (Item 7) for wear or damage. (Replace faulty components if necessary).

8) Replacement of output shaft, bush and seal (as per "Disassembly" and "Assembly" procedures below).

### Disassembly

a. Remove the bevel gear.

b. Remove the circlip and push out the output shaft assembly, including washers (Items 7, 8, 9).

c. Remove the seal.

d. Carefully press out the output shaft bush (If required).




Fig 3

### Assembly

a. Carefully press the new output shaft bush into place (Use Loctite Primer 747, as per instructions, followed by sealant Loctite 262).

b. Insert a new seal into the groove of the output shaft bush.

c. Replace the output gear and washer and replace the circlip to lock the output gear shaft into place.

d. Replace the bevel gear (Item 13) and tighten the grub screw onto flat face of shaft.

9) Place the o-ring (Item 10) into the groove in the cover plate (Replace the o-ring seal if required).

10) Place the cover plate onto the meter.  
Replace the cover plate screws and tighten the six cap head screws (Item 12) firmly.

11) Place the lower cover plate of the register into position. Replace the four screws (Item 15) and tighten.


12) Position the register correctly on top of the lower register cover. Replace the four screws (Item 17) and tighten.

13) Test the meter by turning the rotors with a finger or by applying low air pressure (No more than a good breath) to one end of the meter, before returning meter to the line.

## METER TROUBLE SHOOTING

TROUBLE SHOOTING GUIDE		
TROUBLE	CAUSE	REMEDY
Fluid will not flow through meter	<b>a]</b> Foreign matter blocking rotors <b>b]</b> Line strainer blocked <b>c]</b> Damaged rotors  <b>d]</b> Meter connections over tightened <b>e]</b> Fluid is too viscous	<b>a]</b> Dismantle meter, clean rotors (Strainer must be fitted in line) <b>b]</b> Clean strainer <b>c]</b> Replace rotors (Strainer must be fitted in line) <b>d]</b> Re-adjust connections <b>e]</b> See specifications for maximum viscosity
Reduced flow through the meter	<b>a]</b> Strainer is partially blocked <b>b]</b> Fluid is too viscous	<b>a]</b> Clean strainer <b>b]</b> See specifications for maximum viscosity
Meter reading inaccurate	<b>a]</b> Fluid flow rate is too high or too low  <b>b]</b> Fluid is too viscous <b>c]</b> Excess wear caused by incorrect installation	<b>a]</b> See "specifications" for minimum and maximum flow rates <b>b]</b> Bleed air from system <b>c]</b> Check meter body and rotors. Replace as required. Refer to installation instructions
Fluid flows but no reading on meter	<b>a]</b> Bevel gear is loose on shaft <b>b]</b> Rotor drive gear is damaged <b>c]</b> Transmission gears damaged <b>d]</b> Register gears damaged	<b>a]</b> Tighten grub screws <b>b]</b> Replace rotor <b>c]</b> Replace gears <b>d]</b> Replace register assembly
Fluid leaks into register	<b>a]</b> Seal won or damaged on the cover plate	<b>a]</b> Replace seal (Check seal compatibility with fluid)

## HEATING JACKETS




**Complete Assembly:** HJ400-1 - Aluminium BSP  
HJ400-2 - Aluminium NPT

### Spare Parts Listing:

<b>HJ100-1:</b>	MS320	SHCS Screws
	MS135B	Jacket Body - Aluminium/BSP
	OR812	"O" Ring
<b>HJ100-2:</b>	MS320	SHCS Screws
	MS135N	Jacket Body - Aluminium/NPT
	OR812	"O" Ring

## METER PARTS LISTING




Item No.	No. Off.	Rec. Parts	Part or Set (Order from this column only)	Part Description
1	1		MS520B	Meter Body 2" BSP (Aluminium)
1	1		MS520N	Meter Body 2" NPT (Aluminium)
<b>1</b>	<b>1</b>		<b>MS520-1B</b>	<b>Meter Body 2" BSP (Stainless Steel)</b>
<b>1</b>	<b>1</b>		<b>MS520-1N</b>	<b>Meter Body 2" NPT (Stainless Steel)</b>
1	1		MS483F	Meter Body 2" ANSI 150lb Flange (Aluminium)
1	1		MS483D	Meter Body 2" DIN16 Flange (Aluminium)
<b>1</b>	<b>1</b>		<b>MS481F</b>	<b>Meter Body 2" ANSI 150lb Flange (S/Steel)</b>
<b>1</b>	<b>1</b>		<b>MS481D</b>	<b>Meter Body 2" DIN16 Flange (S/Steel)</b>
2	1	u	BS252s	"O" Ring (NBR)
2	1	u	BS252Es	"O" Ring (EPDM)
2	1	u	BS252TEs	"O" Ring (Teflon)
2	1	u	BS252Vs	"O" Ring (Viton)
<b>3</b>	<b>2</b>	u	<b>MS105-1S</b>	<b>Rotors 316 Stainless Steel with S/Steel Pinion</b>
<b>3</b>	<b>2</b>	u	<b>MS105-2S</b>	<b>Rotors PPS with Stainless Steel Pinion</b>
3	2	u	MS105HS-2S	High Viscosity Rotors (PPS) with S/Steel Pinion
3	2	u	MS105TS-2S	High Temperature Rotors (PPS) with S/Steel Pinion
3	2	u	MS105HTS-2S	High Viscosity/High Temperature Rotors (PPS) S/Steel Pinion
3	1	u	MS105-1HS	High Viscosity Rotors (Stainless Steel) with S/Steel Pinion
4	1		MS232S	Meter Cap Liters (Aluminium)
4	1		MS335US	Meter Cap US Gallons (Aluminium)
<b>4</b>	<b>1</b>		<b>MS233S</b>	<b>Meter Cap Liters (Stainless Steel)</b>
<b>4</b>	<b>1</b>		<b>MS425US</b>	<b>Meter Cap US Gallons (Stainless Steel)</b>
5	6	u	MS243S	Meter Cap Screws (Standard)
<b>5</b>	<b>6</b>	u	<b>MS282S</b>	<b>Meter Cap Screws (Stainless Steel)</b>
6	1	u	MS363S	Complete Gear Set - Liters
6	1	u	MS470S	Complete Gear Set - US Gallons
7	1	u	MS77S	Output Gear & Shaft Assembly
8	1	u	MS78S	Coverplate Seal/Bush Set Standard
8A	1	u	OR42Cs	Solvent o-ring (Chemraz)
9	1	u	MS78C	Coverplate Seal/Bush Set Solvent
9A	1	u	N7-007s	Standard o-ring (NBR)
10	2	u	BS145s	O-ring (NBR)

## METER PARTS LISTING

Item No.	No. Off.	Rec. Parts	Part or Set (Order from this column only)	Part Description
10	2	u	BS145ES	O-ring (EPDM)
10	2	u	BS145TES	O-ring (Teflon)
10	2	u	BS145VS	O-ring (Viton)
11	1		MS99S	Coverplate (Aluminium) includes bush
<b>11</b>	<b>1</b>		<b>MS99-1S</b>	<b>Coverplate (Stainless Steel) includes bush</b>
12	6	u	MS312S	Coverplate Screws - Litre Model
<b>12</b>	<b>6</b>	u	<b>MS313S</b>	<b>Coverplate Screws (Stainless Steel)- Litre Model</b>
12	6	u	MS419S	Coverplate Screws - U.S. Gallon Model
<b>12</b>	<b>6</b>	u	<b>MS420S</b>	<b>Coverplate Screws (Stainless Steel)- U.S. Gallon Model</b>
13	1	u	MS83S	Bevel Gear Set
14	1		MS140	Bottom Register Coverplate
15	4	u	MS111S	Mounting Screws
16	1	u	MS141S	Register Assembly with Coverplate - Liters
16	1	u	MS141US	Register Assembly with Coverplate - US Gallons
17	4	u	MS129S	Register Body Screws
18	1		Customer to specify model	Legend Plate (Not Pictured) includes Hammer Screws
19	1		MS37	Warning Label (Not Pictured)
20	1	u	MS423S	Spacer Ring (Aluminium) U.S. Gallons Model only
<b>20</b>	<b>1</b>	u	<b>MS423-1S</b>	<b>Spacer Ring (Stainless Steel) U.S. Gallon Model only</b>

**Note:** Complete Register Assembly Part Numbers; "Litre" Register - MS84, "US Gallons" Register - MS84U

## METER DIMENSIONS



## METER SPECIFICATONS

### Flow Ranges

(Litre per minute/US Gallons per minute)

**Above 5 Centipoise** 15 to 350/4 to 93

**Below 5 Centipoise** 30 to 300/8 to 79

**Accuracy of Reading** +/- 1%

**Maximum Viscosity\*** 1000 Centipoise

**Maximum Operating Pressure** 1800 kPa / 260 PSI / 18 BAR

**Maximum Operating Temperature\*** 80°C / 176°F (Stainless Steel Models 120°C / 248°F)

Meter conforms to PED 97/23/EC Cat 1.

\* Unless High Viscosity or High Temperature Rotors are fitted

**NOTES:**

## WARRANTY

Macnaught Pty Ltd warrants that the Products will be free from any defects caused by faulty material or workmanship for a period of Twenty Four (24) months from the date of sale of the Products to the end user (the 'Warranty Period') PROVIDED THAT, during the Warranty Period:

1. Macnaught receives notice setting out full details of any defect in any product and details of the time and place of purchase of the Product: and
2. the end user, at its own cost returns the Product to the nearest authorised Macnaught Service Centre.

Macnaught shall, as its option repair or replace and Product found defective by its inspection or refund the price paid by the end user for that Product.

Macnaught liability and the end user's rights under this warranty shall be limited to such repair, replacement or refund and, in particular, shall not extend to any direct, special, indirect or consequential damage or losses of any nature.

**Note:**

This warranty does not form part of, nor does it constitute, a contract between Macnaught and the end user. It is additional to any warranty given by the seller of the Products and does not exclude, limit, restrict or modify the rights and remedies conferred upon the end user, or the liabilities imposed on the seller, by any statute or other laws in respect of the sale of the Product.



Macnaught Pty Ltd  
PO Box 90 Arncliffe NSW 2205 Australia  
Telephone (02) 9567 0401  
Facsimile (02) 9597 7773  
Email: [sales@macnaught.com.au](mailto:sales@macnaught.com.au)  
Web: [www.macnaught.com.au](http://www.macnaught.com.au)