

MARINE WASTE HANDLING SYSTEMS & WASTE COMPACTORS

DT-500GC Glasscrusher in stainless steel



GLASS CRUSHER FOR PASSENGER SHIPS, FERRIES, ENVIRONMENTAL STATIONS ETC.

The DT-500GC is a newly developed glass-crusher from Delitek AS, based upon the design of the DT-500 waste compactor. The glass-crusher is meant for destruction of different types of glass bottles. The outcome from the DT-500GC is small fragments of crushed glass that is collected in "big-bags" inside the container. This makes it very easy to handle this type of recyclable material. The DT-500GC combined with the "big-bag" is an ideal solution in cases where glass bottles is considered as a waste problem. When the "big-bag" is full the container is ready to be rolled out of from the glass-crusher. Finally you can hoist the "big-bag" out from the container and replace with a new one. Get rid of your glass bottle problems by using a Delitek glass-crusher.

SPACE-SAVING AND ECONOMIC

The DT-500GC has a space saving design that makes it ideal to install onboard vessels with limited space onboard. A 500 litres container secures high capacity and longer intervals between each deployment.

EFFECTIVE AND ENVIRONMENTAL FRIENDLY

The output from the glass-crusher is small fragments of crushed glass, which can be delivered directly for recycling or for example used as drainage fillings.

TECHNICAL DATA:

Volume container	0,5 cubic meter
External dimensions (W x D xH)	75mm x 1006mm x 1495mm
Total Height	1495mm
El-system	220V/ 380~480V, 16A, 3 phase
Power consumption	1,5 kW
Weight	236 Kg

