

Regatta Challenger Offshore 150

Regatta Challenger Offshore is a lifejacket designed to give optimal freedom of movement. The lifejacket is comfortable to wear in work situations and provides good buoyancy in an emergency situation. The lifejacket's patented Interlocking lobe design provides an effective wave barrier, which directs the water away from the face.

- Solid PVC-coated cover for easy cleaning and durability
- Adjustable belt with buckle in stainless steel
- Twin automatic independent chambers give higher security
- Fluorescent yellow material and SOLAS reflective tape on lung give high visibility
- Automatic inflation in contact with water
- For manual inflation - use the pull cords or oral tubes
- Equipped with grab loop, whistle and wateractivated light
- Additional equipment: crotch strap, fire resistant "Panotex" cover
- Requires technical inspection and annual maintenance. Read instructions carefully!
- Maintenance: 2 recharge kit (each 33 gr cylinder, bobbin, locking clip) and 2 bobbins



Technical specifications

Buoyancy: 160N
Size: Over 32 kg
Colour: Fluorescent yellow
Weight: 1.2 kg
Operating head: Halkey-Roberts V85000
Approval: Bureau Veritas, Directive 96/98 EC, as amended Directive 2002/75/EC: SOLAS 74 Conv., as amended by 2000 SOLAS Amend., Reg. III/4, X/3, III/7.2 and III/34 – IMO Res. MSC.48(66) (LSA Code) 1.2.2.2 – IMO Res. MSC.97(73) (2000 HSC Code) 8.1, 8.3 – IMO Res. MSC. 81(70), Part. 1 and EN396 150N



regatta.no



Safe at Sea

Regatta AS
Borgundfjordveien 80
N-6017 Ålesund
Phone: +47 70 17 69 00
Fax: +47 70 17 69 01
E-mail: office@regatta.no
www.regatta.no

Dealer: