



FWU - FRESH WATER UNIT

CUSTOM-MADE UNIT

JOWA Fresh Water Units are specially designed for the offshore and marine market. They consist of all necessary equipment for fresh and hot water supply, such as:

- » Calorifiers
- » Hydrophores
- » Filters for various applications
- » Pumps for pressurizing and hot water circulation
- » UV-sterilizer, silver ion sterilizer or chlorination
- » Control cabinet

Sweden
JOWA AB
Tulebovägen 104
S-428 34 Källered
Telephone: +46-31 726 54 00
Telefax: +46-31 795 45 40
website: www.jowa.se
e-mail: info@jowa.se

Norway
JOWA NORGE A/S
Solbergveien 22
3057 Solbergelva
Telephone: +47-3223 6700
Fax: +47-3223 6701
e-mail: post@jowa.no

Germany
JOWA GERMANY GMBH
Hansestrasse 21 / Haus 2
18182 Rostock-Bentwisch
Telephone : +49-381 6302 660
Fax : +49-381 6302 641
website: www.jowa.de
e-mail: info@jowa.de

Netherlands
JOWA HOLLAND
Ebweg 61
2991 LS Barendrecht
Telephone : +31(0)180 55 71 33
Fax : +31(0) 180 61 11 27
e-mail: post@jowa-holland.nl

USA
JOWA CONSILIUM US, INC.
59 Porter Road
Littleton, MA 01460
Telephone: +1-978 486 98 00
Fax: +1-978 486 01 70
website: www.jowa-consilium.com
e-mail: info@jowa-consilium.com

Singapore
JOWA (S) PTE., LTD.
26, Lorong G Telok Kurau
Singapore 426195
Telephone: +65-6872 8802
Fax: +65-6872 8896
e-mail: jowaspdk@singnet.com.sg

China
JOWA (Shanghai)
Marine Equipment Co.,Ltd.
5111 Luo Shan Road, Pudong New Area
Shanghai 201204
Telephone: +86-21-3390 6890
Fax: +86-21-3390 7550
e-mail: jowasha@jowa.com.cn

For many decades now, Jowa has been a trusted and reliable supplier of technical environmental protection equipment to the shipping industry. We can offer every conceivable service for installation, supervision, operation, monitoring and control of Jowa's equipment. You can choose between our own personnel or one of our trained representatives all over the world.

THE JOWA GROUP



Our engineers design a customer-made unit according to customers, specifications, combined with our knowledge and experience.

Before our production starts customer will get complete drawings of the unit with locations and dimensions of all connections.

All equipment is mounted on a common frame with all internal piping and electrical work completed.

Each unit, before leaving our workshop, will pass a quality-test of all functions. The unit is also pressure tested. The only thing left for the customer to do before using the equipment is to connect water inlet and outlets and electrical power supply. Quick and easy installation onboard.

All equipment are of the highest quality. Our calorifiers and hydrophores are made of stainless steel 316L. Pumps are selected from well known brands on the worldwide market. Sterilizers, filters, calorifiers and hydrophores are our own products and design so that spare parts are easily available from anyone of our offices or representatives worldwide.

Main Features

- » Easy to install
- » Compact and flexible design
- » Quick response as all units are from one supplier

