



## HOMOGENIZER SYSTEM

### OPTIMIZE YOUR COMBUSTION

With fuel oil often accounting for more than 40% of a vessels operation costs, efficient combustion is of crucial importance. Furthermore, fuel oil quality can have serious long term implications for engine wear and it's associated costs.

The Homogenizer has been specifically designed to solve the uniformity problems ship owners and operators face when running on heavy fuel oil. There is no better chemical-free approach for best treatment of heavy fuel oil, water-in-fuel-emulsion and sludge.

The equipment incorporates a hermetically sealed magnetic coupling drive and special hard material combination, suitable for very high pressure and temperature applications.

For many decades now, Jowa has been a trusted and reliable supplier of technical environmental protection equipment to the shipping industry. We can offer every conceivable service for installation, supervision, operation, monitoring and control of Jowa's equipment. You can choose between our own personnel or one of our trained representatives all over the world.

THE JOWA GROUP

**Sweden**  
**JOWA AB**  
 Tulebovägen 104  
 S-428 34 Källered  
 Telephone: +46-31 726 54 00  
 Telefax: +46-31 795 45 40  
 website: www.jowa.se  
 e-mail: info@jowa.se

**USA**  
**JOWA CONSILIUM US, INC.**  
 59 Porter Road  
 Littleton, MA 01460  
 Telephone: +1-978 486 98 00  
 Fax: +1-978 486 01 70  
 website: www.jowa-consilium.com  
 e-mail: info@jowa-consilium.com

**Norway**  
**JOWA NORGE A/S**  
 Solbergveien 22  
 3057 Solbergelva  
 Telephone: +47-3223 6700  
 Fax: +47-3223 6701  
 e-mail: post@jowa.no

**Singapore**  
**JOWA (S) PTE., LTD.**  
 26, Lorong G Telok Kurau  
 Singapore 426195  
 Telephone: +65-6872 8802  
 Fax: +65-6872 8896  
 e-mail: jowaspdk@singnet.com.sg

**Germany**  
**JOWA GERMANY GMBH**  
 Hansestrasse 21 / Haus 2  
 18182 Rostock-Bentwisch  
 Telephone: +49-381 6302 660  
 Fax: +49-381 6302 641  
 website: www.jowa.de  
 e-mail: info@jowa.de

**Netherlands**  
**JOWA HOLLAND**  
 Ebweg 61  
 2991 LS Barendrecht  
 Telephone: +31(0)180 55 71 33  
 Fax: +31(0) 180 61 11 27  
 e-mail: post@jowa-holland.nl

**China**  
**JOWA (Shanghai)**  
**Marine Equipment Co.,Ltd.**  
 5111 Luo Shan Road, Pudong New Area  
 Shanghai 201204  
 Telephone: +86-21-3390 6890  
 Fax: +86-21-3390 7550  
 e-mail: jowasha@jowa.com.cn



## Operational Principle

The Homogenizer operates on the principles of mechanical shearing and ultrasonic forces. It utilises a special conical shaped milling gear, to generate high hydrodynamic power consisting of shearing, friction and acceleration forces with pressure waves of high frequency. The high molecular asphaltenes, the existing cat-fines, remaining water etc. are homogenized into heavy fuel oil with maximum particle size of 5  $\mu\text{m}$ .

## Main Features

- » Reduction of fuel oil sludge
- » Increased burnable fuel amount with improved fuel efficiency
- » Improved combustion quality and reduced exhaust emissions
- » Reduced wear on engine components and reduced operational costs
- » For more info see Jowa Germany website [www.jowa.de](http://www.jowa.de)
- » Std - cap 5-8  $\text{m}^3/\text{h}$

