

The Tank Sealer Kit is a quick, easy and flexible first barrier against leakages on storage tanks.

The two sizes of **Miko Plaster**[®] included in the kit are fitted with a neoprene sheet in the centre and magnetic nitrile rubber along the edges. The magnetic rubber will adhere to the steel surface of the tank while the soft neoprene centre will seal against the damage.

External anchor magnets (MAM-003 and MAM-Light) are applied to the outside of the neoprene centre to compress the patch against the damaged area and limit the leakage.

The equipment can be used both above and below the waterline.



DETAILS

Contents

1 pcs	750 x 750 mm Neoprene Miko Plaster [®]
1 pcs	750 x 1 050 mm Neoprene Miko Plaster [®]
2 pcs	MAM-003 Miko Anchor Magnets
4 pcs	MAM-Light Miko Anchor Magnets
1 pcs	IP54-rated storage and transport case

Gross Weight

56 kg

Case Dimensions

785 x 525 x 450 mm

INSTALLATION PRINCIPLE

The **Neoprene Miko Plaster®** is applied over the damaged area, while directing the spray away from the user. The neoprene sheet should cover the damaged area.

One **MAM-003 Miko Anchor Magnet** is placed on the centre of the patch to strangle the leak. The magnet may have to be re-positioned to reduce the leak further.

The kit includes two MAM-003 as well as four **MAM-Light** that are used as needed to achieve best possible seal.



Demonstration video available at www.youtube.com/user/mikomarine

CONTACT

Miko Marine AS
P.O. Box 1534 Vika
N-0117 Oslo
Norway

Website: www.miko.no
E-mail: info@miko.no
Telephone: +47 46 90 50 00

