

The WRV-8000 is an expansion plug intended for sealing pipe openings below the water surface. It is used for planned operations during maintenance, in-water survey or repair, as well as for emergencies and salvage operations.

A watertight seal is established against the inside of the pipe by closing the turning bar, pressing the aluminium disks together and expanding the soft rubber rings. The crossbar prevents the plug from being sucked in. The through-bore and valve (exception: Type A) enable the pipe to be flooded before removing the plug.

Type	No. of Rubber Rings	Nominal Diameter	Chuck Capacity
A	1	18 mm	18 – 21 mm
A	1	25 mm	25 – 28 mm
A	1	35 mm	35 – 42 mm
A	1	40 mm	40 – 50 mm
A	1	45 mm	45 – 55 mm
A	1	55 mm	55 – 65 mm
B	2	60 mm	60 – 65 mm
B	2	70 mm	65 – 75 mm
B	2	80 mm	75 – 85 mm
B	2	90 mm	85 – 95 mm
B	2	100 mm	95 – 105 mm
B	2	110 mm	105 – 115 mm
B	2	125 mm	120 – 135 mm
B	2	130 mm	125 – 145 mm
B	2	140 mm	135 – 155 mm
B	2	150 mm	145 – 165 mm
B	2	160 mm	155 – 175 mm
B	2	190 mm	185 – 205 mm
B	2	200 mm	195 – 210 mm
B	2	210 mm	205 – 225 mm
B	2	225 mm	220 – 240 mm
B	2	250 mm	245 – 270 mm
B	2	260 mm	255 – 280 mm
B	2	275 mm	270 – 295 mm
B	2	300 mm	295 – 315 mm
C	3	325 mm	320 – 333 mm
C	3	350 mm	335 – 358 mm
C	3	375 mm	360 – 383 mm
C	3	400 mm	385 – 410 mm
C	3	425 mm	410 – 435 mm
C	3	450 mm	435 – 460 mm
C	3	500 mm	485 – 510 mm
C	3	600 mm	585 – 610 mm



CONTACT

Miko Marine AS
P.O. Box 1534 Vika
N-0117 Oslo
Norway

Website: www.mikomarine.com
E-mail: info@miko.no
Telephone: +47 46 90 50 00