



Fire Fighting Units



NORWEGIAN
maritime equipment

MARITIME

OFFSHORE

The worldwide marketplace

Fire Fighting Units

For ships, offshore vessels and industrial use

- Portable units for quick installation on deck.
- Fixed installations in engine room.
- Monitors with remotecontrol from bridge or manual operation.
- Units are tested by full load before delivery. All to be witnessed by Class representative and documented by issuing a certificate.

Example

1200m³/h standardunit consist of the following

- Dieselenigne. (Caterpillar, MTU etc)
- Flex coupling between engine and pump
- Pump in cast iron, with impeller in bronze and AISI 316 shaft
- 24V or airdriven vacuumsystem for first priming to the pump
- Batteries, exhaustsilencers w/ sparkarrestors
- Switch cupboard with engine alarms and controls for running pump
- Monitor el. operated or manuel in emergency
- All built on a common lifting frame with dieseltank and nylon protctioncovers on sides. Steelplate on roof
- All the above to be painted in RAL-3000(red)
- The units are loadtested and equipped with Lloyds witness certificate



Suctionside of pump



Switch cupboard



Vacuum system

NORWEGIAN
maritime equipment

P.O Box 244, 5480 Husnes, Norway
Tel. +47 53 47 95 00 · Fax + 47 53 47 34 99
E-mail: nme@nme.no www.nme.no

Safety equipment

- Lifeboats – totally enclosed / partially enclosed /open
- Freefall Lifeboats • Rescue / Fast Rescue Boats
- Davits - ship and rig davits / rescue boat davits / liferaft davits

Deck equipment

- Deck Cranes • Offshore Cranes • A-frames • Capstans
- Winches - mooring / tugger / hoisting etc • Windlasses

Other equipment

- Anchors • Chains • Reverse Osmosis Plants • Sewage Treatment Plants • Accommodation Modules • Firefighting systems
- Purifier • Fenders • Various Maritime / Offshore Equipment

Click or [call us](#)

Manufacturing and supply Rental Installation Service